

File: SERVICE MANUAL - Section 140  
Replaces: Nothing  
Dist: 3, 3a, 3b, 3c

## XLP3 Evaporative Condenser



**THIS MANUAL CONTAINS RIGGING, ASSEMBLY, START-UP, AND MAINTENANCE INSTRUCTIONS. READ THOROUGHLY BEFORE BEGINNING INSTALLATION. FAILURE TO FOLLOW THESE INSTRUCTIONS MAY RESULT IN PERSONAL INJURY OR DEATH, DAMAGE TO THE UNIT, OR IMPROPER OPERATION.**

## Table of Contents

<b>INSTALLATION</b>		<b>COLD WEATHER OPERATION</b> .....	<b>18</b>
<b>INTRODUCTION</b> .....	<b>4</b>	Inspection and Maintenance .....	18
Safety .....	4	Fan Section Icing Protection .....	18
Shipping.....	4	<b>BASIN WATER AND INTERNAL PIPING</b>	
Pre-Rigging Checks .....	4	<b>FREEZE PROTECTION</b> .....	<b>18</b>
Cold Weather Operation.....	4	Cold Water Basin Protection.....	18
Location.....	4	<b>COIL FREEZE PROTECTION</b> .....	<b>19</b>
Warranties.....	4	Minimum Operation.....	19
Unit Operation .....	5	<b>OPERATION CONSIDERATIONS</b>	
<b>RIGGING &amp; ASSEMBLY</b> .....	<b>5</b>	<b>FOR ACCESSORIES</b> .....	<b>19</b>
Rigging .....	5	Basin Heater (Optional) .....	19
Section Assembly .....	5	Stand Alone Frick Heater Control Panel (Optional) .....	19
Table 1 - Recommended Vertical Dimension and Spreader		Operation .....	19
Bar Length .....	5	<b>VIBRATION CUTOFF SWITCH (VCOS)</b> .....	<b>20</b>
Wiring the Factory Terminal Box (EC Fan System Only).....	7	Mechanical Vibration Cutout Switch (Standard).....	20
<b>OPTIONAL ACCESSORY INSTALLATION</b> .....	<b>8</b>	Electronic Vibration Cutout Switch (Optional) .....	20
Bottom Water Outlet (Optional) .....	8	<b>FAN CONTROL</b> .....	<b>22</b>
Offset Access Platform, Perimeter Guardrail and Ladder....	8	EC Fan System Fan Control.....	22
Ladder Safety Cage (Optional) .....	10	Independent Fan Control (Optional).....	22
Table 2 - Ladder Safety Cage Bolting Location and			
Quantities .....	10	<b>MAINTENANCE</b>	
Automatic Bearing Greasers (Optional for Belt Drive Fan		<b>DETAILED COMPONENT</b>	
System Units Only) .....	11	<b>MAINTENANCE PROCEDURES</b> .....	<b>24</b>
Heater Control Panel (Optional).....	11	Cold Water Basin .....	24
<b>FIELD CONNECTIONS</b> .....	<b>13</b>	Table 4 - Cold Water Basin Water Levels .....	24
Table 3 - Supplies for Installing Field Connections.....	13	EC Fan System.....	24
		Belt Drive Fan System .....	24
		Water Distribution System and Heat Transfer Section.....	26
		Water Level Control.....	27
		<b>CORROSION PROTECTION</b> .....	<b>28</b>
		Water Treatment .....	28
		Corrosion and Scale Control.....	28
		Gray Water and Reclaimed Water.....	29
		Chemical Treatment Requirements .....	29
		Table 5 - Quality Guidelines for Treated Circulated Water	29
		Passivation .....	29
		Biological Control .....	29
		Long Term Care of Stainless Steel .....	30
		Jobsite Considerations.....	30
		System Cleaning.....	30
		<b>BLEED RATE</b> .....	<b>30</b>
		<b>RECOMMENDED MAINTENANCE INTERVALS</b> .....	<b>32</b>
<b>OPERATION</b>			
<b>SAFETY PRECAUTIONS</b> .....	<b>14</b>		
<b>START-UP PROCEDURE</b> .....	<b>15</b>		
Considerations for Initial Start-Up .....	15		
General.....	15		
Cleaning.....	15		
Inspection .....	15		
Start-up.....	15		
<b>EXTENDED SHUTDOWN</b> .....	<b>16</b>		
<b>PROLONGED OUTDOOR STORAGE</b> .....	<b>16</b>		
Storage Preparation .....	16		
Motor Recommendations .....	17		
Electronically Commutated (EC) Motors.....	17		
Belt Drive Fan System .....	17		
Maintenance Requirements During Storage.....	18		
Start-Up Preparation After Prolonged Storage.....	18		

### SAFETY PRECAUTION DEFINITIONS

	<b>DANGER</b>	Indicates an imminently hazardous situation which, if not avoided, will result in death or serious injury.
	<b>WARNING</b>	Indicates a potentially hazardous situation or practice which, if not avoided, will result in death or serious injury.
	<b>CAUTION</b>	Indicates a potentially hazardous situation or practice which, if not avoided, will result in damage to equipment and/or minor injury.
	<b>NOTICE</b>	Indicates an operating procedure, practice, etc., or portion thereof which is essential to highlight.

Factory Pre-Assembled Lader with Safety Cage (Optional)

Coil Connection: Refrigerant Vapor In

Coil Connection: Refrigerant Liquid Out

Terminal Box

Pump

**XLP3 Evaporative Condenser with EC Fan System**

Factory Pre-Assembled Platforms with Perimeter Handrails (Optional)

BranchLok™ Removal System

Coil

EC Fan System

Access Door with Safety Handle and Step

Internal Walkway

Strainer

Basin

**XLP3 Evaporative Condenser with EC Fan System**



**XLP3 Evaporative Condenser with Belt Drive Fan System**

**XLP3 Evaporative Condenser**

# INSTALLATION

## INTRODUCTION

### Safety

Adequate precautions appropriate for the installation and location of these products should be taken to safeguard the equipment and the premises from damage, and the public from possible injury. **The procedures listed in this manual must be thoroughly reviewed prior to rigging and assembly. Read all warnings, cautions and notes.**

When the fan speed of the unit is to be changed from the factory set speed, including the use of a variable speed device, steps must be taken to avoid operating at or near the fan's "critical speed" which could result in fan failure and possible injury or damage. Refer to "Fan Control" in the Operation section of this manual.

**⚠ WARNING**

**In the event of extended lifts or where hazards exist, the lifting devices should be used in conjunction with safety slings placed under the unit.**

### Shipping

Frick XLP3 Evaporative Condensers are factory assembled to ensure uniform quality with minimum field assembly. As standard, models ship in two sections per cell (lower and upper). Contact your local Frick Representative for more information. For the dimensions and weights of a specific unit or section, refer to the submittal drawings.

**⚠ WARNING**

**Only personnel qualified to do so should undertake the installation, operation, maintenance, and repair of this equipment. Proper care, procedures, and tools must be used in handling, lifting, installing, operating, maintaining, and repairing this equipment to prevent personal injury and/or property damage.**

### Pre-Rigging Checks

When the unit is delivered to the job site, it should be checked thoroughly to ensure all required items have been received and are free of any shipping damage prior to signing the bill of lading.

**The following parts should be inspected (if applicable for the unit's configuration):**

- |  |  |
|--|--|
| <input type="checkbox"/> Sheaves, Belts, and Bearings<br><input type="checkbox"/> Bearing Supports<br><input type="checkbox"/> Fan Motor(s)<br><input type="checkbox"/> Fan Guard(s)<br><input type="checkbox"/> Fan(s) and Fan Shaft(s)<br><input type="checkbox"/> Float Valve Assembly(s)<br><input type="checkbox"/> Water Distribution System | <input type="checkbox"/> Coil Surface<br><input type="checkbox"/> Cold Water Basin Accessories<br><input type="checkbox"/> Interior Surfaces<br><input type="checkbox"/> Exterior Surfaces<br><input type="checkbox"/> Spray Water Pumps<br><input type="checkbox"/> Mating Surfaces Between Sections/ Modules |
|--|--|

Miscellaneous Items: All bolts, nuts, washers, and sealer tape required to assemble sections or component parts are furnished by Frick and shipped with the unit. A checklist inside the envelope marked "Customer Information Packet" indicates what miscellaneous parts are included with the shipment and where they are packed. This envelope will be attached to the side of the unit or located in a box inside the unit.

### Unit Weights

Before rigging any unit, the weight of each section should be verified from the unit submittal drawing. Unit print weights include the final assembled unit with all accessories. Accessory weights (found on the respective drawing) can be deducted from the total weight.

### Anchoring

Seven-eighths inch (7/8") diameter holes are provided in the bottom flange of the basin section for bolting the unit to the support beams. Refer to the suggested support drawing included in the submittal for location and quantity of the mounting holes. **The unit must be level for proper operation.** Anchor bolts must be provided by others. The IBC rating is only certified with standard anchorage locations. Using alternate anchorage locations or alternate steel supports will void any IBC wind or seismic ratings. Contact your local Frick Representative for details.

**⚠ CAUTION**

**Unit must be properly anchored in place before operation begins.**

### Cold Weather Operation

These products must be protected by mechanical and operational methods against damage and/or reduced effectiveness due to possible freeze-up. Refer to "Cold Weather Operation" in the Operation section of this manual or contact your local Frick Representative for recommended protection alternatives.

**⚠ WARNING**

**Before an actual lift is undertaken, ensure no water, snow, ice, or debris has collected in the basin or elsewhere in the unit. Such accumulations will add substantially to the equipment's lifting weight.**

### Location

All evaporative cooling equipment must be located to ensure an adequate supply of fresh air to the fans. When units are located adjacent to walls or in enclosures, care must be taken to ensure the warm, saturated, discharge air is not deflected and redirected back to the air intakes. Each unit must be located and positioned to prevent the introduction of discharge air into the ventilation systems of the building on which the unit is located and of adjacent buildings. For detailed recommendations on Frick equipment layout, contact your local Representative.

**NOTICE**

**Each unit must be located and positioned to prevent the introduction of discharge air into the ventilation systems of the building on which the unit is located and of adjacent buildings.**

### Warranties

Please refer to the Limitation of Warranties (located in the submittal package) applicable to and in effect at the time of the sale/purchase of these products.

**Unit Operation**

Prior to start-up and unit operation, refer to the Frick Operation & Maintenance sections in this manual.

**RIGGING & ASSEMBLY**

**Rigging**

Refer to Table 1 for the recommended vertical dimension “H” from the lifting device to the spreader bar. In the event of extended lifts or where hazards exist, the lifting devices should be used in conjunction with safety slings placed under the unit.

**NOTICE**

For weight information, refer to the submittal drawing package.

**NOTICE**

Any motors or accessories shipped in the cold water basin must be removed prior to installing the upper (mechanical and coil casing) section.

Most single cell XLP3 Evaporative Condenser products are designed to be lifted in one assembled piece as shown in Figure 1. Verify the total unit shipping weight is below 35,000 lbs before performing a single-piece lift. A two-piece lift is shown in Figure 2.

**WARNING**

Single piece lift is ONLY possible when total unit shipping weight is under 35,000 lbs. Please refer to the shipping weight shown on the Unit Print from submittal package. Single piece lifting must be done using lifting ears on the base of the upper casing section (See Figure 1).

**Section Assembly**


1. Remove any motors or accessories shipped in the cold water basin. Rig the basin section. The rigging hook must be placed above the section’s center of gravity as detailed in Figures 1 and 2.
2. Wipe down the flanges with acetone to remove dirt or moisture which may have accumulated during shipment and storage.

3. Install sealer tape on the mating flange of the bottom section to ensure an airtight seal between the top and bottom section. Install flat butyl sealer tape (Frick part #554000) supplied with the unit, on the mating flanges of the lower section in a continuous line. At each corner, allow 1” overlap. See Figure 3.

**CAUTION**

Before proceeding, bolt the basin sections securely to the supporting steel.

4. Lower the flexible connection on the pump discharge piping below the elevation of the lower section before rigging the coil casing section.
5. Lower the upper section (coil casing and mechanical) until it is hovering 2-6” above the lower section.
6. Insert drift pins per Figure 5. Start at the corner hole and skip every 3 or 4 holes along the length of the unit, inserting drift pins to align the coil casing section and the lower section holes. Repeat this process on the other side.
7. Fasten the hardware between the coil casing and lower section per Figure 4. Lower the coil casing section the rest of the way onto the lower section, keeping mounting holes aligned.



**Figure 1 – Single-Piece Lift**

**Table 1 – Recommended Vertical Dimension and Spreader Bar Length**

Model Number	Number of Basin Sections	Number of Casing Sections	Basin Section			Casing Section or Single Piece Lift	
			Spreader Bar Length (L)	Minimum Height (H)	Center of Gravity from Air Inlet Face	Spreader Bar Length (L)	Minimum Height (H)
XLP3-1012xxxx-xxxx	1	1	10'	13'-8"	4'-2"	10'	9'-2"
XLP3-1018xxxx-xxxx	1	1	10'	13'-8"	4'-2"	10'	13'-8"
XLP3-1024xxxx-xxxx	2	2	10'	13'-8"	4'-2"	10'	9'-2"
XLP3-2012xxxx-xxxx	2	2	10'	13'-8"	4'-2"	10'	9'-2"
XLP3-1036xxxx-xxxx	2	2	10'	13'-8"	4'-2"	10'	13'-8"
XLP3-2018xxxx-xxxx	2	2	10'	13'-8"	4'-2"	10'	13'-8"
XLP3-1212xxxx-xxxx	1	1	12'	13'-8"	5'	10'	9'-2"
XLP3-1218xxxx-xxxx	1	1	12'	13'-8"	5'	10'	13'-8"
XLP3-1224xxxx-xxxx	2	2	12'	13'-8"	5'	10'	9'-2"
XLP3-2412xxxx-xxxx	2	2	12'	13'-8"	5'	10'	9'-2"
XLP3-1236xxxx-xxxx	2	2	12'	13'-8"	5'	10'	13'-8"
XLP3-2418xxxx-xxxx	2	2	12'	13'-8"	5'	10'	13'-8"




Figure 2 – Two-Piece Lift

8. Secure the hose connecting the sections of the pump discharge pipe with the hose clamps provided.
9. On units with more than one casing, install the remaining casings using the same procedure as the first. When installing two or more casings, on the basin section, sealer tape must be applied to both cross flanges (see Figure 3).
10. On units operating with a remote sump tank, install a bleed line with valve between the system circulating pump discharge riser and a convenient drain. Locate the bleed line in a portion of the riser piping that drains when the pump is off. Units that are furnished with a factory-installed circulating pump include a bleed line with valve.




Figure 3 – Sealer Tape Application




Figure 4 – Fastening of Upper and Lower Sections



Figure 5 – Section Alignment Using Drift Pins

**CAUTION**  
Before proceeding, bolt the basin sections securely to the supporting steel.

**Wiring the Factory Terminal Box (EC Fan System Only)**

**Electrical Power Quality**

This unit requires clean electrical power to operate properly. Voltage and frequency should be within 10% of the designed voltage for the unit. Failure to provide this power may damage the unit. The EC fan motors contain built-in protection circuits that will shut down the fan if there is a power quality issue. If the fans go into protection mode, the unit must be shut down and restarted to return to normal operation.

**⚠ WARNING**

**When connecting power to the unit, do not penetrate the top of the control panel. Doing so may allow moisture to enter the panel. All cable and conduit should be supported separately from the unit. Do not penetrate the unit for supports or other connections.**

**Power Connections**

The XLP3 Condenser requires a 3 phase 60Hz power source (50Hz also available). The voltages available are 200 to 240V and 380V to 480V. Please ensure that the correct voltage is supplied to the unit. If unsure, check your unit's submittal to verify that the provided power matches your unit. On the factory terminal box, remove the NEMA plug located on the side of the panel near the disconnect switch. This will maintain the panel's NEMA 4 rating and prevent water ingress to the unit.

**NOTICE**

**Any motors or accessories shipped in the cold water basin must be removed prior to installing the upper (mechanical and coil casing) section.**

**Controls Connections**

The controls wiring should be provided in a separate conduit from any power wiring. Frick recommends penetrating the control panel from the bottom or side panel observing standards. It is also recommended to use shielded wire to avoid interference.

To control the XLP3 Evaporative Condenser fan speed, a control signal of 4-20mA is used. The signal commands the fans off at 4mA and full speed at 20mA. The 4-20mA should be wired as outlined in the wiring diagram in the submittal package. Control wiring can be routed into the terminal box through the NEMA plug located on the bottom of the panel.




Figure 6a – Terminal Box Location




Figure 6b – Terminal Box

### OPTIONAL ACCESSORY INSTALLATION

#### Bottom Water Outlet (Optional)

1. The bottom connection seal, Figure 7, is typical for all bottom remote sump outlets. Flange mounting hardware and gasket to be supplied by others.
2. Bottom connection seal kit(s) ship in plastic tubs.




Figure 7 – Bottom Water Outlet

#### Offset Access Platform, Perimeter Guardrail and Ladder

1. Lift the platform by fastening the lifting device to the top guard rail so it does not slide while lifting. Lift the platform so that the support gussets align with the mounting brackets on the unit. See Figure 8.
2. Fasten the platform gussets to the mounting brackets using the supplied hardware as shown in Figure 8, Detail A.
3. Loosely fasten the lower and intermediate appropriate ladder brackets and diagonal braces to the factory installed ladder brackets as shown in Figure 8, Detail B and Figure 9, Detail A. Check your submittal for the ladder orientation ordered. Attach the ladder to the platform and fasten the lower and intermediate brackets to the ladder side rails as shown in Figure 8, Detail B and Figure 9, Detail A.
4. Tighten all ladder bracket fasteners.
5. Cut the ladder to length required and fasten the ladder foot to the landing surface (anchorage hardware provided by others).
6. Using the supplied hardware, install the perimeter guardrails at the bracket points as shown in Figure 10, Detail A and Detail B.
7. At the point where two vertical support meet, install the factory supplied fastener through each support as shown in Figure 10, Detail C.

**NOTICE**

For platform and ladder options ordered but not listed, refer to the customer information packet supplied on the unit.




Figure 8 – Platform Installation and Air-Intake Face (Face D) Ladder Installation

Detail B. Intermediate and Lower Ladder Bracket






Figure 9 – End Ladder Installation





Figure 10 – Perimeter Guardrail Installation

**Ladder Safety Cage (Optional)**

1. If the safety cage is shipped in multiple pieces, reassemble the safety cage.
2. Bolt the safety cage to the ladder using flatwashers and lock-nuts. Orient all fasteners with bolt heads inside safety cage. See Figure 11, Detail A through D and refer to Table 2 for the quantity of bolting locations for different safety cage heights.

NOTICE

Safety gates are provided for all handrail openings, and all components are designed to meet OSHA requirements.




**Figure 11 – Safety Cage**

**Table 2 – Ladder Safety Cage Bolting Location and Quantities**

Cage Height (ft)	Bolting Location				Cage Height (ft)	Bolting Location				Cage Height (ft)	Bolting Location			
	A	B	C	D		A	B	C	D		A	B	C	D
4	1	-	-	1	12	1	1	2	1	20	1	1	4	1
5	1	1	-	1	13	1	1	2	1	21	1	1	4	1
6	1	1	-	1	14	1	1	2	1	22	1	1	4	1
7	1	1	-	1	15	1	1	2	1	23	1	1	4	1
8	1	1	-	1	16	1	1	2	1	24	1	1	4	1
9	1	1	1	1	17	1	1	3	1	25	1	1	5	1
10	1	1	1	1	18	1	1	3	1	27	1	1	5	1
11	1	1	1	1	19	1	1	3	1					

**Automatic Bearing Greasers (Optional for Belt Drive Fan System Units Only)**

1. Verify the mounting brackets are factory installed.
2. Fill the extended lube lines with Frick compatible water resistant grease using a manual grease gun. See the "Fan Shaft Bearings" in the Maintenance section of this manual.
3. Thread automatic bearing greasers into 3/8" x 1/4" adapters on mounting brackets.
4. For programming, operation, and troubleshooting of the greaser, consult the user manual shipped with the greaser. This manual is also available through your local Frick Representative.



**Figure 12 – Automatic Bearing Greasers**

**Heater Control Panel (Optional)**

1. Carefully plan the location of the control panel. Measure the factory supplied probe cord length. Do not attempt to change the cord length.
2. After selecting the installation site, mount the control panel with four 5/16" (field supplied) bolts through the mounting feet on the enclosure.
3. The main incoming power hub and the main power termination points are sized for wires based on the total nameplate kW and voltage. The actual load for a particular installation may be less. Either compute the actual load on the heater control panel (the total kW of all the heaters connected to it) or use the nameplate rating to determine the wire size required. The field supplied branch circuit disconnect switch and the branch circuit protective devices (fusing or circuit breaker) should be sized per NEC or local code requirements.

4. Connect the incoming power wire conduit to the incoming power hub provided on the control panel. Make sure the connection is water tight and secure. Pull the incoming power wire into the control panel enclosure and make connections per the control panel-wiring diagram.
5. Connect the heater power wire conduit(s) to the heater power wire hub(s) provided on the control panel. Make sure the connection is watertight and secure. Pull the heater power wire into the control panel enclosure and make the connections per the control panel wiring diagram. Conduit connections to multiple heaters should run until the conduit terminates at the last heater. Jumping from one heater to the next is not recommended.
6. If the heater has a thermal cutoff, wire the cutoff back to the terminal block in the panel per the wiring diagram. This is a Class 1 circuit and can be in the same conduit as the power wiring. If there are two or more heaters, connect the cutoffs in series as shown in the wiring diagram.
7. If alternative conduit hubs are drilled, or if supplied hubs are not used, replace the plastic protective caps inside the hubs with steel plugs.
8. If leakage or condensation is likely to occur in the conduit runs leading to the control panel, install a drain in the bottom of the control panel and form a conduit loop.
9. Verify operation by following the "Stand Alone Frick Heater Control Panel" in the Operation section of this manual.

**NOTICE**

1. The heater control panel should be within sight of the heater if a disconnect switch option is selected.
2. Maintain a water level at least 2" over the heaters by ensuring proper operation of make-up water level control. Low water may lead to over temperature conditions near the heater.
3. All power wiring should have a temperature rating of 167°F (75°C), and be rated for the number of wires in the conduit.
4. The wiring should be sized for the quantity of incoming wires in the conduit and the amperage of the branch circuit protective device as directed by the NEC/CEC, or any other local directives.
5. If non-metallic conduit is used, provide a circuit grounding conductor that meets NEC/CEC requirements. Ground lugs are provided in the heater control panel.

**NOTICE**

Figure 13 is superseded by any drawing supplied with the panel by the manufacturer.




Figure 13 – Example Wiring Diagram for Stand Alone Frick Heater Control Panel (Refer to Submittal Drawing for Specific Wiring Diagram)

## FIELD CONNECTIONS

The following are installation instructions for adding new field connections (Equalizer/Bypass/Outlet) on a cold water basin with the TripleGuard® Corrosion Protection System.


**Table 3 – Supplies for Installing Field Connections**

Supplies Provided by Frick	Recommended Supplies Provided by Others
Template for the connection with bolt holes	Stainless steel threaded shoulder bolts
Type 304 stainless steel backing ring with gasket	150 lb flange, weld any piping to the flange prior to installation
Vulkem® Caulk	Gasket for the outside of the cold water basin

1. Use the Frick template provided with the accessory to layout and mark the hole pattern on the exterior of the cold water basin.
2. Drill a pilot hole from the outside of the cold water basin to the inside of the cold water basin.
3. On the inside of the cold water basin:
  - a. For connections 3" or less, score the TripleGuard® Corrosion Protection System with a hole saw as shown in Figure 14.
  - b. For connections 3" or greater, proceed to step 4.
4. Cut the hole from the outside of the cold water basin.
  - a. Use a hole saw or a step drill bit for smaller connections 3" or less as shown in Figure 15.
  - b. Use a reciprocating saw or a Sawzall® for larger connections 3" or greater.
5. Position the Frick supplied stainless steel backing ring gasket to the inside of the cold water basin.
6. Position the flange to the outside of the cold water basin.
7. Bolt the flange and the stainless steel backing plate together using stainless steel bolts.
8. Seal any exposed galvanized steel of the connection inside the cold water basin with Vulkem® Caulk as shown in Figure 16.

### NOTICE

**Frick recommends adding a flange connection for field installed equalizers, bypass and outlet connections. Please order the recommended supplies listed in Table 3 prior to unit shutdown.**



**Figure 14 – Scored TripleGuard® Corrosion Protection System**



**Figure 15 – Removal Material**



**Figure 16 – Caulk Exposed Galvanized Steel**

## OPERATION

### SAFETY PRECAUTIONS

#### DANGER

Rotating equipment will cause severe personal injury or death to persons who come in contact. Do not perform any service on or near the fans, motors, and drives, or inside the unit without first ensuring that the fans and pump motors are disconnected, locked out, and tagged out.

#### WARNING

- The top horizontal surface of the unit is not intended to be used as a walking surface or working platform. If access to the top of the unit is desired, the purchaser/end-user is cautioned to use appropriate means complying with OSHA or other applicable safety standards of governmental authorities.
- When the fan speed of the unit is to be changed from the factory set speed, including changes achieved by the use of a variable fan speed device, steps must be taken to avoid operation at or near the fan's "critical speed" which could result in fan failure and possible personal injury or damage. Contact your local Frick Representative regarding any such applications.
- The recirculating water system may contain chemicals or biological contaminants, including Legionella, which could be harmful if inhaled or ingested. Personnel exposed directly to the discharge airstream and the associated drift mists, generated during operation of the water distribution system and/or fans, or mists produced by high pressure water jets or compressed air (if used to clean components of the recirculating water system), must wear respiratory protection equipment approved for such use by governmental occupational safety and health authorities.
- A lockable disconnect switch should be located within sight of the unit for each fan motor associated with this equipment. Before performing any type of service or inspection, make certain that all power has been disconnected, and the switch is locked out in the "OFF" position.

#### CAUTION

- The operation, maintenance, and repair of this equipment shall be undertaken only by personnel authorized and qualified to do so. All such personnel shall be thoroughly familiar with the equipment, the associated system and controls, and the procedures set forth in this manual. Proper care, personal protective equipment, procedures, and tools must be used in handling, lifting, installing, operating, maintaining, and repairing this equipment to prevent personal injury and/or property damage.
- This equipment should never be operated without all fan screens, access panels, and access doors in place.

#### CAUTION

- All electrical, mechanical, and rotating machinery are potential hazards, particularly for those not familiar with their design, construction, and operation. Accordingly, use appropriate lockout procedures. Adequate safeguards (including the use of protective enclosures where necessary) should be taken with this equipment both to safeguard the public from injury and to prevent damage to the equipment, its associated system, and the premises.
- Openings and/or submerged obstructions may exist in the bottom of the cold water basin. Use caution when walking inside this equipment.
- Do not use the plastic drift eliminators as a walking, working, or storage surface. Stepping on or placing weight on an eliminator can result in physical injury and/or equipment damage. After ensuring that the fan and pump motors are locked and tagged out, lift and remove eliminators as necessary to perform recommended maintenance and inspections. If access to the top of the coil is required, place a piece of plywood at least 1/2 inch thick on top of the coil to protect the surface while performing the recommended maintenance. When finished, carefully remove the plywood and re-install any eliminators which were removed.
- Combined inlet shields can separate from the product during high winds. Fasten combined inlet shields in place using the retaining system.

#### NOTICE

- Frick units are typically installed immediately after shipment and many operate year round. However, if the unit is to be stored for a prolonged period of time either before or after installation, certain precautions should be observed, as outlined in "Unit Operation and Storage" on page 15.
- Mechanical and operational methods must be employed to protect these products against damage and/or reduced effectiveness due to possible freeze-up. Please contact your local Frick Representative for recommended protection alternatives.
- The basin heater is not designed to prevent icing during unit operation.
- The heater control panel temperature/low level control can only be used with the supplied combination temperature/liquid level sensor probe.
- For the stand alone Frick heater control panel, do not operate the system unattended or for extended periods of time during test mode (resistor across terminals T1 and T2). Operation in water temperatures above 45°F (7.2°C) could damage the unit.
- For heater control panels, do not operate the system unattended or for extended periods of time with terminals G1-G2 jumpered. A low liquid level condition could occur, and the system will not shut off which could result in damage to the heater and unit.

## NOTICE

- Check to ensure the controls for the fan motor are set to allow a maximum of six on-off cycles per hour to prevent motor overload.
- With a switching frequency of 2.5 kHz, the line lead length cannot exceed 100 feet. If the switching frequency is higher than 2.5 kHz and/or the line lead length exceeds 100 feet, a dV/dT output filter is recommended to protect the motor.
- For fan motors controlled with VFDs, when reversing the direction of fan rotation, allow the fan to come to a complete stop before restarting the motor.
- Only lubricate the bearings with one of the compatible water resistant greases listed on page 26.
- Do not use steam or high pressure water to clean PVC eliminators or materials other than steel.
- Spray system pressure greater than 10.0 psig may cause damage to the distribution system.
- Never use chloride or chlorine based solvents such as bleach or muriatic (hydrochloric) acid to clean stainless steel. It is important to rinse the surface with warm water and wipe with a dry cloth after cleaning.

## START-UP PROCEDURE

### Considerations for Initial Start-Up

- For units with independent fan control [standard on units with the Belt Drive Fan System], see page 22.
- For units with VFDs, see page 22.
- For units with vibration cutout switches, see page 20.

### General

- If the unit is mounted on vibration isolators or isolation rails (by others), refer to the vibration isolation manufacturer's guidelines before loading/unloading weight from the unit.
- Verify fans and the pump motor are disconnected, locked out, and tagged out.
- The unit must be level in both the length and width directions for proper operation.

### Cleaning

- Drain the cold water basin with the strainer in place.
- Remove all dirt and debris from the fan guard(s) and combined inlet shields.
- Inspect and clean all spray nozzles.
- Clean all of the mechanical components, such as the fan and motor.
- Flush the cold water basin to remove any accumulated dirt and debris.
- Remove, clean, and replace the basin strainer.

## DANGER

**Rotating equipment will cause severe personal injury or death to persons who come in contact. Do not perform any service on or near the fans, motors, and drives, or inside the unit without first ensuring that the fans and pump motors are disconnected, locked out, and tagged out.**

### Inspection

- Conduct external inspection of the equipment. Check for leaks, corrosion, and any structural damage.
- Conduct internal inspection of the equipment. Check for anything unusual such as structural or mechanical component damage.
- Inspect piping and connections.
- Thoroughly inspect the fans for any mechanical or physical damage.
- At seasonal start-up or after prolonged shutdown, check the motor insulation with an insulation tester prior to the motor start-up.
- Check and adjust the belt tension. Units equipped with the EC Fan System use direct drive motors and do not require belt tension.

### Start-up

- For Belt Drive Fan System units only, prior to seasonal start-up, lubricate the motor base adjusting screw (see Figure 22 on page 25) and the fan shaft bearings (see page 26). At initial start-up, no bearing lubrication is required since the bearings are factory lubricated prior to shipment.
- For Belt Drive Fan System units only, apply RUST VETO® to steel shafts.
- Fill the cold water basin with fresh water to the overflow level via the make-up valve.
- Set the make-up valve float so the water shuts off at the operating level (see Table 4 on page 24).
- Execute one of the following biocide treatment programs while operating the circulating pump and prior to operating the unit fans:
  - Resume treatment with the biocide that was used prior to shutdown. Operate the pump only while maintaining the maximum recommended biocide residual for a sufficient duration (residual and time will vary with the biocide) as recommended by the water treatment supplier. Start the fan only after this treatment period is completed.
  - Check the pH of the circulating water and, if necessary, adjust it to 7.0 - 7.6 pH. Then, running the pump only, treat the system with sodium hypochlorite to maintain a level of 4 to 5 mg/l (ppm) free chlorine (as Cl<sub>2</sub>) over a six hour period. Test kits for measuring the free residual of chlorine are commercially available. Start the fan only after this treatment period is completed.
- Start the unit pump and check for the proper rotation indicated by the arrow on the pump cover.
- On installations where the unit pump was not furnished by Frick, a globe valve should be installed in the pump discharge line and the pump flow rate adjusted to the correct water flow and pressure (2.25 psig at spray header connection).
- Check that the float operated make-up valve is operating freely. Closely monitor the water level and adjust as necessary during the first 24 hours of operation.

- Inspect the nozzles and heat transfer section as described in “Water Distribution and Heat Transfer Section” on page 26.
- For units with the Belt Drive Fan System, verify proper fan tip clearance. See page 24.
- Open the valve in the unit bleed line, and adjust the bleed by closing or opening the valve until the desired bleed rate is reached.
- For initial start-up, briefly energize the fan motor(s) and note the direction of rotation. The fan should rotate in the direction indicated by the arrow on the fan cowl.
- Run the fan in manual mode for several minutes to check for any unusual noise or vibrations.
- For a 2-speed motor, check to ensure the starter includes a minimum 15 second time delay when switching from high speed to low speed.
- Check the operation of the optional vibration cutout switch.
- Once the unit is operating, check the current and voltage of all three phases (legs) of the fan motor with a heat load on the unit under warm ambient conditions. The current must not exceed the motor nameplate rating.

## NOTICE

**Spray system pressure greater than 10.0 psig may cause damage to the distribution system.**

## NOTICE

**Check to ensure the controls for the fan motor are set to allow a maximum of six on-off cycles per hour to prevent motor overload.**

**After 24 hours of operation under thermal load, perform the following services:**

- Check the unit for any unusual noises or vibrations.
- Check the operating water level in the cold water basins.
- Adjust the make-up valve if necessary.
- Check the belt tension and readjust if necessary.
- Inspect the spray nozzles and heat transfer section.

## EXTENDED SHUTDOWN

## DANGER

**Rotating equipment will cause severe personal injury or death to persons who come in contact. Do not perform any service on or near the fans, motors, and drives, or inside the unit without first ensuring that the fans and pump motors are disconnected, locked out, and tagged out.**

**Perform the following services whenever the evaporative condenser is shut down in excess of 3 days:**

- If the unit is mounted on vibration isolators or isolation rails (by others), refer to the manufacturer’s guidelines before loading/unloading weight from the unit.

- Disconnect, lock out, and tag out the fans, pump, and motors.
- Close the shut-off valve in the make-up water line (supplied by others), and drain the cold water basin and all exposed water piping. Heat trace and insulate all exposed piping.
- To minimize the risk of biological contamination during shutdown, it is recommended the entire system be drained.
- Clean all debris, such as leaves and dirt, from the interior and exterior of the unit, including the combined inlet shields.
- Clean and flush the cold water basin with the basin strainer in place.
- Leave the cold water basin drain open so rain and melting snow will drain from the unit.
- Remove the bottom drain plug to the spray pump(s). Put the plug(s) in a marked plastic bag and attach to the spray pump(s) for future use.
- Clean the basin strainer and re-install.
- Cover the fan discharge to keep out dirt and debris.
- Lubricate the fan shaft bearings, motor base, and motor base adjusting screw (if applicable).
- Apply RUST VETO® to steel shafts (for Belt Drive Fan System units only).
- Inspect the protective finish on the unit. Clean and refinish as required. Refer to “Corrosion Protection” on page 28 for more details.
- Lockout the fan motor starting device in the “OFF” position to ensure personal safety in case of future inspection or service.

## PROLONGED OUTDOOR STORAGE

### Storage Preparation

- Conduct the “Extended Shutdown” procedure on page 16 if the unit is installed.
- Ensure the cold water basin is fully drained and the drain is open.
- For storage prior to installation, all components and accessories, which sometimes ship inside the unit and are not a permanent fixture in the basin, should be removed and stored indoors.
- Remove the bottom drain plug to the spray pump(s). Put the plug(s) in a marked plastic bag and attach to the spray pump(s) for future use.
- Remove and store fan belts (if supplied) at room temperature. Tag belts appropriately for future identification.
- **Precautions:**
  - **Storage Prior to Installation** – The coils should be charged with nitrogen at 15 psig at the factory.
  - **Extended Shutdown Periods after Start-Up** – The coils should be charged with nitrogen at 15 psig in the field and capped by adding a threaded connection or a welded cap. Upon start-up, the coil connections will require cutting and bevelling.



- Apply a weather-resistant lubricant or heavy grease such as Anti-Seize (Frick Part # 160069) to all exposed threaded or flanged connections and the adjustable motor base threaded rod.
- Insert desiccant bags into the control panel (if supplied) to absorb moisture. Seal the control panel for storage.
- Spray coat electrical component housings (if supplied) with a suitable protective coating, such as Cosmoline® Weathershed, and individually cover them with plastic, taking care to leave openings for free air circulation.
- Inspect the protective finish on the unit. Clean and refinish as required. Refer to "Corrosion Protection" on page 28 for more details.

**Motor Recommendations**



**Figure 17a – XLP3 Evaporative Condenser with EC Fan System**



**Figure 17b – XLP3 Evaporative Condenser with Belt Drive Fan System**

**Electronically Commutated (EC) Motors**

XLP3 Evaporative Condenser EC motors are designed for storage at ambient temperatures of -40°F to 176°F (-40°C to 80°C). Prolonged periods of exposure above or below these specified conditions could degrade components of the motor and cause malfunction or premature failure.

- Care must also be taken to protect the motor from flooding or from harmful chemical vapors.
- The storage area should be free from ambient vibration. Excessive vibration can cause damage.
- Keep stored motor(s) dry and protected from weather.
- Rotate the fan once per month.
- Precautions should be taken to prevent rodents, snakes, birds, or other small animals from nesting inside the motors. In areas where they are prevalent, precautions must also be taken to prevent insects from gaining access to the interior of the motor.

**⚠ DANGER**

**Rotating equipment will cause severe personal injury or death to persons who come in contact. Do not perform any service on or near the fans, motors, and drives, or inside the unit without first ensuring that the fans and pump motors are disconnected, locked out, and tagged out.**

**Belt Drive Fan System**

Frick standard motors are designed for storage at ambient temperatures of -20°F to 104°F (-28.9°C to 40°C). Prolonged periods of exposure above or below these specified conditions could degrade components of the motor and cause malfunction or premature failure.

- Motors should be removed and stored inside whenever possible. When indoor storage is not possible the motors must be covered with a tarpaulin. Do not use plastic or plastic film. This cover should extend below the motor and be secured; however, it should not tightly wrap the motor. This will allow the captive air space to breathe, minimizing formation of condensation.
- Care must also be taken to protect the motor from flooding or from harmful chemical vapors.
- The storage area should be free from ambient vibration. Excessive vibration can cause bearing damage.
- Precautions should be taken to prevent rodents, snakes, birds, or other small animals from nesting inside the motors. In areas where they are prevalent, precautions must also be taken to prevent insects from gaining access to the interior of the motor.
- If not stored indoors in a controlled environment, some form of heating must be utilized to prevent condensation from accumulating in the motor. This heating should maintain the winding temperature at a minimum of 9°F (5°C) above the ambient temperature of the surrounding environment, keeping it from dropping below the dew point where condensation could form inside the motor. If space heaters are supplied, they should be energized. Request the required voltage and transformer capacity from your local Frick Representative. A third option is to use an auxiliary heat source and keep the winding warm by either convection or blowing warm air into the motor.
- Rotate the motor shaft monthly to redistribute bearing grease.

## Maintenance Requirements During Storage

- Rotate all fans and motor shafts monthly by hand. Hand-turning will ensure that the shafts and bearings are free and will redistribute grease within the bearings.
- Inspect the cold water basin monthly to ensure that the drain is open and remove any leaves or debris that may have accumulated in the cold water basin.
- Inspect the axial fans annually to ensure the blades are tight and there is no obvious corrosion between the hub and the fan blade.
- Inspect the rust preventative coating on all motor external machined surfaces including shaft extensions monthly. If necessary, re-coat the surfaces with RUST VETO®.

## Start-Up Preparation After Prolonged Storage

Keep in mind that start-up procedures after long periods of storage are just as important as pre-shutdown procedures.

- Motors should be thoroughly inspected, cleaned, and restored to pre-storage condition.
- Inspect axial fans prior to start-up to ensure that the blades are tight and that there is no obvious corrosion between the hub and the fan blade. Do not energize the fans if there is obvious corrosion of fan components. Loose fan blades could result in fan failure and possible injury or damage.
- Reinstall all fan belts, motors, door gaskets, and drain plugs (as applicable), and remove all protective coverings.
- For units stored prior to installation, conduct rigging procedures as directed in the unit's Rigging and Assembly Instructions, or by contacting your local Frick Representative.
- Perform an insulation test of motor windings to ensure satisfactory insulation resistance.
- Conduct full start-up procedure as stated in the "Start-Up Procedure" on page 15. Be especially thorough for cleaning and inspection prior to start-up.

## COLD WEATHER OPERATION

### Inspection and Maintenance

Frick products can be operated at subfreezing ambient temperatures provided proper operating methods are established and diligently followed.

- Carry out frequent visual inspections and routine maintenance services during operation in subfreezing weather.
- Ensure all controls for capacity and freeze protection are set properly and functioning normally.
- Prevent excessively high water levels and possible overflow of the cold water basin due to over pumping, clogged strainers, or make-up valve malfunction.
- Some unit icing can be expected in very cold weather. Usually this will not affect the operation of the unit. Resolve any icing conditions that may damage the unit or the supports, impair the system performance, or create a safety hazard.

## Fan Section Icing Protection

There are three basic operational methods which can be used to provide the system's required cooling: temperature setting, fan control, and dry operation. The method of control employed on a given application depends upon the climatic extremes which are expected, the variations in heat load that will be encountered, and the compatibility of the control system with other portions of the installation.

In subfreezing ambient temperatures, effective icing control may require a combination of these three methods. Operate each unit with the highest thermal load it can handle, rather than evenly dividing the total heat load across all cells. During prolonged cold weather periods, bypass the idle units and drain the basins.

### Fan Control

Reduce the unit capacity by cycling the fans, thus modulating the airflow through the unit. Rapid on-off cycles can cause the fan motor to overheat. Set the controls to allow a maximum of six on-off cycles per hour. Periodically, cycle the fans off to prevent ice formation and/or to melt ice that accumulates on the combined inlet shields.

The following are fan control methods:

- **Variable Frequency Drives:** VFDs offer the most precise method of capacity control by modulating fan motor speed. When using VFDs, avoid operating at or near resonant speeds. Units with VFDs require premium efficient/inverter duty motors.
- **Fan Cycling:** Cycle the fan off for five minutes every 15 to 20 minutes for each cell. If ice continues to build on the air intake, decrease the on-time. Observe the air intake of the unit at least every four to eight hours.

## NOTICE

**Modulating the water flow rate to the unit is NOT a recommended method of controlling cooling capacity.**

### Dry Operation

One method to prevent icing is dry operation. Dry operation of the unit protects fans from ice formation due to mist and splash from the cold water basin. The water in the cold water basin must be drained in dry operation. For dry operation switch points and recommendations, contact your local Frick representative.

## BASIN WATER AND INTERNAL PIPING FREEZE PROTECTION

### Cold Water Basin Protection

It is important to protect the basin and internal piping. The basin water could freeze when the unit is shutdown and exposed to subfreezing ambient temperatures.

- **Remote Sump:** The ideal method of protection is a remote sump located in a heated indoor space. When the circulating pump stops, the water in the connecting piping will drain by gravity to this indoor sump.
- **Basin Heaters:** On applications without a remote sump, heat must be provided to the cold water basin. Electrical immersion heaters can provide the required function. Contact your local Frick Representative for details.

- **Electric Water Level Control:** An electric water level control will maintain the proper water level regardless of the thermal load or variations in make-up water supply pressure. The two-position, slow closing solenoid valve provided with the Frick electric water level control package also minimizes valve freezing problems (see page 28).
- **Heat Tracing:** Heat trace and insulate all exposed water piping including pump piping below the overflow level and make-up water lines with electrical heater tape.

## NOTICE

For remote sump applications, the water level in the basin of the equipment is a function of the design flow rate, the quantity, size and location of the remote sump connection and the pipe design between the cooling tower and the remote sump. Units installed on remote sump applications are supplied without a make-up connection.

### COIL FREEZE PROTECTION

For protection against coil freeze-up, recommended solutions are an industrial grade inhibited ethylene glycol or propylene glycol solution. When the use of glycol is not practical, the system must be designed to meet both minimum flow and minimum temperature requirements.

Coil volumes for the XLP3 Evaporative Condenser using liquid cooling circuits is job specific.

#### Minimum Operation

When utilizing an auxiliary cooling circuit with water as the cooling media, the system must be operated to meet minimum flow and temperature requirements. Maintain a minimum heat load so that the temperature of the fluid leaving the coil is not less than 50°F (10°C).

To maintain the leaving fluid temperature at 50°F (10°C) when the process load is extremely light or shut off, apply an auxiliary heat load to the circulating fluid and adjust the flow to ensure that fluid leaving the coil maintains the minimum required temperature. Otherwise, a glycol solution can be used as the cooling media to prevent freezing.

### OPERATION CONSIDERATIONS FOR ACCESSORIES

#### Basin Heater (Optional)

One or more electric immersion heaters prevent the cold water basin from completely freezing over and damaging the unit during shutdown or standby. The heaters are sized for the specific unit. The heating element has an enclosure that is suitable for outdoor use. Annually, inspect the basin heater prior to the risk of reaching freezing operating conditions.

#### Operation

Ensure that the heating element is completely submerged before energizing the main disconnect. For installations that have a Frick Controls Enclosure, please consult the submittal packet provided with the unit and contact your local Frick Representative for support. For installations that use a stand alone heater control panel, see below.

## NOTICE

The basin heater is not designed to prevent icing during unit operation.



Figure 18 - Basin Heater

#### Stand Alone Frick Heater Control Panel (Optional)

The heater control system consists of a heater control panel and a combination temperature/water level sensor. The stainless steel sensor probe with 1/2" NPT mounting fitting has an on/off relay output that de-energizes the heaters whenever the basin water temperature is above 45°F (7.2°C), or whenever the sensor probe is not fully submersed. The control panel enclosure is suitable for outdoor use.

The control system utilizes a combination temperature/low water level control sensor, which is powered by a transformer in the control panel. When the sensor provides a signal to the control panel, the panel sends a control voltage to the magnetic contactors. When energized, the magnetic contactors supply line voltage to the heaters. Annually inspect the heater control system prior to the risk of reaching freezing operating conditions.

## NOTICE

The heater control panel temperature/low level control can only be used with the supplied combination temperature/water level sensor probe. Please contact your local Frick Representative for replacement parts.

#### Operation

Ensure that the element is completely submerged before energizing the main disconnect. The combination temperature/low level control is preset to energize the heater at 40°F (4.5°C), but will not energize if the water level is too low or if the water temperature is above 45°F (7.2°C).

#### Testing the heater when water temperatures are above 45°F (7.2°C):

- Disconnect the heater control panel and tag out the circuit.
- Remove the heater control panel cover.
- Remove the sensor wires connected to terminals T1 and T2 on the combination temperature/low level control and isolate them.

- Install the 1.5K ohm test resistor supplied with the heater control panel (in bag on outside of cover) across terminals T1 and T2.
- Install the heater control panel cover.
- Energize the system and listen for the contactor closing.
- After operation, de-energize the circuit, disconnect the heater control panel, and tag out the circuit.
- Remove the resistor and place it back in the storage bag. Check all connections, reconnect sensor wires per the wiring diagram to terminals T1 and T2, replace the cover, and place the system back in service.

### WARNING

Dangerous voltages are present in this equipment. Disconnect the electrical service of the source and tag the circuit out before servicing or replacing components.

### NOTICE

Do not operate the system unattended or for extended periods of time during test mode (resistor across terminals T1 and T2). Operation in water temperatures above 45°F (7.2°C) could damage the unit.

#### Operation when the sensor probe is encased in ice:

- Disconnect the heater control panel and tag out the circuit.
- Remove the heater control panel cover.
- Install a jumper wire across terminals G1 and G2 on the combination temperature/low level control circuit board.
- Install the heater control panel cover.
- Energize the system and listen for the contactor closing.
- Operate the system until the ice is melted around the probe.
- After operation, de-energize the circuit, disconnect the heater control panel, and tag out the circuit.
- Remove the jumper, check all connections, replace the cover, and place the system back in service.

### NOTICE

Do not operate the system unattended or for extended periods of time with terminals G1-G2 jumpered. A low liquid level condition could occur, and the system will not shut off which could result in damage to the heater and unit.

### NOTICE

Figure 19 is superseded by any drawing supplied with the panel by the manufacturer.

## VIBRATION CUTOUT SWITCH (VCOS)

The Mechanical Vibration Cutout Switch and the Optional Electronic Vibration Cutout Switch should be tested and field adjusted at start-up and yearly thereafter. Both are located on the outside of the unit, next to the access door.

For units equipped with the EC fan drive system, vibrations are monitored by built-in sensors in the motors. A separate vibration cutout switch is not needed.

### Mechanical Vibration Cutout Switch (Standard)

#### Set Point Adjustment When Installed:

1. For safety, turn off, then lock and tag-out the electrical supply to the fan motor(s).
2. Turn adjustment screw counterclockwise 1/8 turn at a time until you hear the control trip.
3. Once tripped, rotate adjustment screw 1/4 turn clockwise. Push in the manual reset button.
4. Start up the fans to determine if the start-up will cause the cut-out switch to trip.
5. If the VCOS does not trip, start and stop the fan two more times. If the VCOS still does not trip, then calibration is complete.
6. If the VCOS trips, follow the steps in the note to the right.

#### Electrical Reset and Start-up Lockout (Optional):

1. If rated voltage is continuously applied to the reset circuit at unit start-up, the reset solenoid energizes for a fixed time interval (approximately 30 sec), after which time the solenoid is automatically de-energized by the thermistor. This provides a trip lockout during machine start-up roughness.
2. The voltage must be removed from the reset circuit when the machine is stopped to allow the thermistor to cool off.
3. The switch mechanism can be reset electrically by a momentary application of the reset voltage or it can be reset manually.

### Electronic Vibration Cutout Switch (Optional)


Two models of electronic vibration cutout switches are available. The single set point model contains one trip limit for shutdown. The dual set point model contains two independent trip limits; one for alarm and one for shutdown. The shutdown set-point is factory set at 0.45 in/sec. Additional details can be found in the submittal packet.

#### Testing:

- The test position sets in the minimum set point so that any vibration will cause a trip condition.
- The light will come on immediately, and the trip will occur after the duration of the time delay, proving the complete system is operational.
- If test position is maintained for less than the duration of the time delay, the trip will not occur, thus permitting the system test without shutdown.

#### Calibration:

- A light adjacent to the set point control comes on the instant the measured vibration level exceeds the set point.
- The unit can be periodically calibrated on line by turning the set point control down until the light comes on. This setting is then compared with the vibration measured with a portable vibration meter, thus providing a calibration check of the unit.
- If the trip setting is maintained, trip will occur after the duration of the time delay.



**Figure 19 – Example Wiring Diagram for Stand Alone Frick Heater Control Panel (Refer to Submittal Drawing for Specific Wiring Diagram)**

**Remote Reset:** Connection of between terminals 5 and 6 latches triac output in alarm state after set point is exceeded. Opening the connection will reset the output to non-alarm state.

**NOTICE**

If the VCOS trips, turn off, then lock and tag out the electrical supply to the fan motor(s). Adjust the set point screw an additional 1/4 turn clockwise, and push in the manual reset button. Start up the fan motor(s) to determine if the start-up will cause the VCOS to trip. Repeat this adjustment process until the VCOS no longer trips when the unit is operated. Make sure to lock out and tag out the electrical supply to the fan motor(s) before entering the unit or re-setting the switch, each time an adjustment to the VCOS is made. After the final adjustment has been made, start and stop the fan motor(s) two more times to ensure that the VCOS is properly set.




Figure 20 – Electronic VCOS with Alarm Contact is shown

### FAN CONTROL

#### EC Fan System Fan Control

All EC fan motors are controlled simultaneously by a single 20mA analog signal where 4mA is 0% speed and 20mA is 100% speed.

**NOTICE**

With evaporative cooling, a 15 second fan motor delay will not be noticed when staging up.

#### Independent Fan Control (Optional)

Independent fan control is standard on all XLP3 Condensers that are equipped with Belt Drive Fan System. In an operating forced draft unit with independent fan capabilities and no partitions, idle fans tend to windmill in the reverse direction. A windmilling fan poses no threat to the system while turning freely, but can create a large shock load when the fan motor is suddenly powered up. Proper staging of fans when starting from a windmilling condition will prevent excessive stresses on the drive system. There are two control strategy options:

- **VFD:** The recommended control option is to use a variable frequency drive to control all of the motors. VFDs regulate motor speed electronically and start motors with reduced voltage and frequency. The result is a gentle motor start, and therefore reduced stress.

#### • No VFD

- **Staging Up:** Turn all motors off for 15 seconds. Following the 15 second delay, bring all required fans online. Allow for a 1 second time delay between fan stages to reduce staging current.
- **Staging Down:** Turn off the fan motor. No need for delays.

**NOTICE**

For a unit with a VFD, with a switching frequency of 2.5 kHz, the line lead length cannot exceed 100 feet. If the switching frequency is higher than 2.5 kHz and/or the line lead length exceeds 100 feet, a dV/dT output filter is recommended to protect the motor. Since the switching frequency and maximum line length requirements vary between VFD and motor suppliers, contact your local Frick Representative to determine if a dV/dT filter is required.

#### Variable Frequency Drive Operation

- Applications utilizing variable frequency drives (VFDs) for fan motor control must use inverter duty motors built in compliance with NEMA standard MG-1, Part 31.
- Operation of the unit at a speed which resonates with components of the drive system or support structure may result in vibrations which could damage the components or structure, and/or create objectionable noise. Therefore, these resonant speed ranges should be identified at start-up and locked out to prevent operation of the motor at these resonant speeds. The "Resonant Speed Identification Procedure" must be conducted on page 22.
- Please refer to the manufacturer's variable frequency drive recommended start-up procedure for further information or consult with your local Frick Representative for any VFD applications.

**NOTICE**

The minimum turndown ratio for units with a belt drive is 10:1 (or 6 Hz). Units with the oil pump do not have a minimum speed.

#### Resonant Speed Identification Procedure

There are several characteristic frequencies at which vibration levels may resonate with unit structural components. These include fan speed, motor speed, bearing frequency, and blade pass frequency. Within the overall operating speed range of a unit, it is not unusual for one or more of these characteristic frequencies to excite the structural components over relatively small speed ranges and create an increase in vibration levels. If the vibration levels are excessive at these resonant speeds, they need to be locked out to prevent the VFD from operating the motor at these speeds. The following procedure describes how to identify the lockout speed ranges:

- Ensure the VFD that controls the fan motor is off, and the power to the motor circuit is locked out.
- Attach the accelerometer (provided by others) onto the box beam as shown in Figure 21. The accelerometer should be placed on the top of the bearing support channel, near the fan side bearing, as shown.

## NOTICE

The resonant speed identification procedure must be performed at start-up for units with VFDs.

## ⚠ DANGER

Rotating equipment will cause severe personal injury or death to persons who come in contact. Do not perform any service on or near the fans, motors, and drives, or inside the unit without first ensuring that the fans and pump motors are disconnected, locked out, and tagged out.




Figure 21 – Accelerometer Location - Belt Drive

- Connect the signal wire from the accelerometer (provided by others) to the vibration analyzer (provided by others). Be sure to route and fasten the wire so that it will not contact any rotating parts inside the unit when the drive system is operational.
- Get out of the unit, and ensure that the drive system is “all clear”. Remove the lockout from the motor circuit.
- With the VFD off, record the vibration level indicated on the vibration analyzer, and confirm that it is very low (only picking up ambient vibration). Record this overall vibration level (0-peak) in inches per second (ips). If the ambient vibration level is greater than 0.35 ips, identify and correct the cause of the vibration. It could be vibration transmitted from another source, instrumentation malfunction, radio frequency interference, etc. If the cause

is vibration transmitted from another source, and that source cannot be isolated or turned off for the duration of the measurements, note the source and magnitude of the vibration before continuing.

- After it is confirmed that the drive system is “all clear” and the unit access doors are closed, turn the VFD on, and verify that the fan is turning in the correct direction.
- Using the VFD, slowly (about 1 RPM increase every five to ten seconds) adjust the motor speed from the lowest limit to full speed while monitoring the vibration levels. Record the overall vibration levels at regular intervals if desired.
- As stated previously, when adjusting the VFD speed, proceed slowly while monitoring the vibration levels. If the vibration value approaches 0.35 ips (0-peak), slowly “zero in” on the speed where the value equals 0.35 ips, and record the speed at which this occurs as the lower end of the lockout range. Also record the vibration level at this speed.
- Continue to slowly increase the speed while monitoring the vibration level. If this is a resonance, then the value should peak and eventually decrease to a level that is below 0.35 ips as the speed is increased. After the vibration level has peaked and continues to fall, record the speed where the value equals 0.35 ips as the upper end of the lockout range.
- Using this data, a baseline for vibration history can be developed. The vibration levels can be monitored yearly and the trend used to indicate potential wear or the need to replace components in the drive system.
- After the entire speed range has been checked and any resonances identified, ensure the VFD that controls the fan motor is then turned off, and the power to the motor circuit is locked out.
- Enter the unit, and carefully remove the accelerometer, along with any associated wiring from the unit.
- Work with the VFD contractor to enter the lockout speed ranges, if any have been identified, into the VFD, so the unit will not operate at a resonant speed.
- Once it has been verified that the drive system is all clear, return the unit to its normal operating condition.
- Keep a record of any lockout speed ranges for future reference.

**MAINTENANCE**

**DETAILED COMPONENT  
MAINTENANCE PROCEDURES**

**Cold Water Basin**

The cold water basin is constructed from one of the following materials of construction and the following maintenance applies to all basin materials of construction.

- Galvanized steel
- TripleGuard® Corrosion Protection System
- Welded Type 304 stainless steel

**Water Levels**

**Table 4 – Cold Water Basin Water Levels** (Measured From Inside the Cold Water Basin)

Model Number	Operating Depth (in)	Operating Height (in)	Operating Volume (gal)	Overflow Volume (gal)
XLP3-1012xxxx-xxxx	9	15.43	254	479
XLP3-1018xxxx-xxxx	9	15.43	385	701
XLP3-1024xxxx-xxxx	9	15.43	508	959
XLP3-1036xxxx-xxxx	9	15.43	770	1402
XLP3-2012xxxx-xxxx	9	15.43	508	959
XLP3-2018xxxx-xxxx	9	15.43	770	1402
XLP3-1212xxxx-xxxx	9	15.43	254	521
XLP3-1218xxxx-xxxx	9	15.43	385	774
XLP3-1224xxxx-xxxx	9	15.43	508	1,042
XLP3-1236xxxx-xxxx	9	15.43	770	1,549
XLP3-2412xxxx-xxxx	9	15.43	508	1,042
XLP3-2418xxxx-xxxx	9	15.43	770	1,549

- Height is measured from unit's base (mounting point) to water level. Depth is measured from the interior basin floor to water level.
- The operating water level in the cold water basin will vary with system thermal load (evaporation rate), the bleed rate employed, and the make-up water supply pressure.
- The make-up valve controls the operating level, which should be maintained at the levels shown in Table 4.
- Check the operating water level monthly, and readjust the float when necessary to maintain the recommended operating level.

**Inspection & Maintenance**

- Inspect the cold water basin monthly. Remove trash or debris that may have accumulated in the basin or on the strainer.
- Quarterly, or more often if necessary, drain, clean, and flush the entire cold water basin with fresh water. This will remove the sediment, which can collect in the basin during operation. If not removed, sediment can become corrosive and cause deterioration of the protective finish of metallic basins.
  - When flushing the basin, leave the strainer in place to prevent the sediment from re-entering the spray pump.
  - Remove the strainer after the basin has been flushed.
  - Clean and replace the strainer before refilling the basin with fresh water.

- Adjust the float to maintain the design operating level. See Table 4.

**⚠ CAUTION**

**Openings and/or submerged obstructions may exist in the bottom of the cold water basin. Use caution when walking inside this equipment.**

**EC Fan System**

For units supplied with electronically commutated (EC) motors, very little maintenance is required. As the fans are provided with sealed bearings, lubrication is not required.

- With the fans running, check for any unusual noises or vibrations.
- Thoroughly inspect the fans for damaged or deteriorated fan blades and replace the fan system as required.
- After prolonged shutdowns, check the motor insulation with an insulation tester prior to restarting the motor.

**⚠ DANGER**

**Rotating equipment will cause severe personal injury or death to persons who come in contact. Do not perform any service on or near the fans, motors, and drives, or inside the unit without first ensuring that the fans and pump motors are disconnected, locked out, and tagged out.**

**Belt Drive Fan System**

- If the unit is already in operation, while the fan is running, check for any unusual noises or vibrations.
- With the fan off and the fan motor disconnected, locked out, and tagged out, check the general condition of the fan:
  - Inspect for any loose or missing bolts in the fan shaft bushing, the fan hub, and the fan shaft bearing(s).
  - Check the fan blades for looseness, first by twisting the blade by hand, and then by moving the blade tip forward and back. There should be no play or slippage.
  - Inspect each blade for excessive scale build-up that could cause vibration.
  - Check each blade for any cracks. If cracks are found, the fan motor should be locked out until the fan is replaced. Contact your local Frick Representative for assistance.
- **Tip Clearance:** Check the clearance between the tip of the blade and the fan cowl. The clearance should be between 3/16" to 1/4".

**⚠ DANGER**

**Rotating equipment will cause severe personal injury or death to persons who come in contact. Do not perform any service on or near the fans, motors, and drives, or inside the unit without first ensuring that the fans and pump motors are disconnected, locked out, and tagged out.**

- **Blade Pitch:** Check to ensure that the blades are all at the same pitch. If uncertain, measure the pitch with an inclinometer. All blades should be within 1/2° of each other.



- **Rotation:** Turn the fan by hand to ensure that it moves freely with no rough spots, binding, or other malfunctions that could cause vibration or fan motor overload. While rotating the fan, check the blade tracking. All blades should track within a 1/2" band at any single point around the cowl.
- **Direction of Rotation:** On initial start-up, or if the fan motor has been rewired, briefly energize the fan motor and note the direction of rotation. It should rotate in the direction indicated by the arrow on the fan cowl. On units with independent fan motors, check the rotation of each fan.
- **Operation:** On initial start-up, run the fan in the manual position for several minutes, and check for any unusual noises or vibrations.


## NOTICE

**Check to ensure the controls for the fan motor are set to allow a maximum of six on-off cycles per hour to prevent motor overload.**


### Drive System Inspection & Maintenance

The Belt Drive Fan System requires a periodic check of the belt condition and, when necessary, tension adjustment. The recommended service intervals are as follows:

- **Initial Start-up:**
  - **Externally Mounted Motor:** The motor base assembly has been pre-aligned at the factory. Mount the motor base assembly to the unit and verify alignment. Install the belt and follow the belt tensioning directions below.
  - **Seasonal Start-Up:** Readjust the belt tension (if required).
- **Operation:** After the first 24 hours of operation, readjust the belt tension on a new unit start-up or installation of a new belt. Thereafter, check the belt condition monthly, and adjust tension as necessary. Readjust tension at least once every three months.
- **Belt tension check:**
  - Place a straight edge along the belt from sheave to sheave as shown in Figure 22a, or use a tape measure as shown in Figure 22b to measure belt deflection.
  - Apply a moderate force by hand (approximately 40 lbs/275 kPa) evenly across the width of the belt in the center of the span between the sheaves.
  - There is adequate belt tension if the belt deflects between 1/4" and 3/8" as shown in Figures 22a and 22b.




**Figure 22a – Belt Tension with a Straight Edge**



**Figure 22b – Belt Tension with a Tape Measure**

- **Belt tension adjustment (if required):**
  - Using a wrench or impact gun, turn the motor base adjusting screw (Figure 23) clockwise to tension the belt or counterclockwise to relieve belt tension. During adjustment of the belt tension, rotate the drives several times by hand to evenly distribute the tension throughout the belt.



**Figure 23. Motor Adjusting Screw**

## NOTICE

**If belts are properly tensioned, there should be no "chirp" or "squeal" when the fan motor is started.**

- **Drive alignment check and adjustment:**
  - Place a straight edge across the driver and the driven sheaves as shown in Figure 24.
  - The straight edge should contact all four points as shown in Figure 24 indicating that the drives are properly aligned.
  - There should be no more than 1/16" deviation from the four points of contact.
  - In case of realignment, loosen the driver sheave, and align it with the driven sheave. Allow 1/4" for draw-up as the bushing screws are retightened.

## ⚠ DANGER

**Rotating equipment will cause severe personal injury or death to persons who come in contact. Do not perform any service on or near the fans, motors, and drives, or inside the unit without first ensuring that the fans and pump motors are disconnected, locked out, and tagged out.**




Figure 24. Drive Alignment

#### Adjustable Motor Base

Coat the motor base slides and adjusting screws (refer to Figure 23) prior to start-up, every three months while in operation, and following shutdown. Use good quality, corrosion inhibiting grease such as one of those recommended for lubricating the fan shaft bearings below.

#### Fan Motor Inspection & Maintenance

- Clean the outside of the motor at least quarterly to ensure proper motor cooling.
- After prolonged shutdowns, check the motor insulation with an insulation tester prior to restarting the motor.
- Check the motor voltage and current following start-up and every three months while in operation.

### NOTICE

**Check to ensure the controls for the fan motor are set to allow a maximum of six on-off cycles per hour to prevent motor overload.**

#### Fan Shaft Bearing Inspection & Maintenance

- For all units ordered with the Belt Drive Fan System, two pillow block ball bearings support the fan shaft and are provided with extended lube lines as standard on the XLP3 Evaporative Condenser. Each bearing is equipped with a lubrication fitting and a locking collar to keep out moisture.
- Only lubricate the bearings with a manual grease gun or Frick's optional Automatic Bearing Greaser. Do not use high-pressure grease guns since they may rupture the bearing seals or the extended lubrication lines.
- Only lubricate the bearings with one of the following compatible water resistant greases which are suitable for ambient temperatures ranging from -65°F (-53.9°C) to +250°F (121.1°C).
  - Amoco - Rycon Premium #3
  - Chevron - SRI
  - Citgo - Polyurea MP2™
  - Conoco - Polyurea 2™
  - Exxon - Polyrex® EM
  - Exxon - Unirex N™
  - MobilGrease® - AW2
  - Shell - Gadus S2 V100 3
  - Shell - Gadus S3 T100 2
  - SKF - LGHP2™
  - Unocal 76 - Unilife Grease™

- Lubricate the bearings as follows:
  - **Initial Start-Up:** Normally, no lubrication is required since the bearings have been lubricated at the factory prior to shipment. However, if the unit has been stored at the job site for more than three months, both bearings should be lubricated with new grease before initial operation. When lubricating, purge the old grease from the bearing by gradually adding grease until a bead of new grease appears at the seal on the underside of the bearing.
  - **Seasonal Start-Up:** Purge the bearings with new grease prior to start-up.
  - **Operation:** Purge the bearings with new grease every three months while in operation.
  - **Extended Shutdown:** Purge the bearings with new grease prior to any prolonged storage or downtime.

#### Locking Collars

Each eccentric locking collar should be checked quarterly to ensure that the inner bearing race is secured to the fan shaft. The locking collar can be set using the following procedure (see Figure 25):

- Loosen the set screw.
- Using a drift pin or center punch, tap the collar (in the hole provided) tangentially in the direction of rotation while holding the shaft.
- Retighten the set screw.




Figure 25 – Locking Collar Assembly

#### Water Distribution System and Heat Transfer Section

Water is distributed through a corrosion resistant polyvinyl chloride (PVC) spray distribution system. The drift eliminators are made of PVC, which requires no protection against rot, decay, rust, or biological attack.

The inspection procedure is as follows:

- Shut off the fan and lock out and tag out the fan and pump motors.
- Remove drift eliminators to allow a clear view of the spray distribution system and nozzle patterns.
- Start the recirculating pump. Make sure the fan motor is locked out and tagged out. Check to see if the nozzles are all spraying consistently and producing the spray pattern shown in Figure 26.
- Clean any nozzles that are clogged. If necessary, the nozzle and rubber grommet may be removed for cleaning. If additional cleaning is necessary the branch may be

removed for cleaning. With the BranchLok™ System, tools are not required to remove the branches.

- Inspect the coil surface. Any corrosion, damage, or obstructions must be corrected.
- The coil is designed for seasonal dry operation followed by seasonal wet operation, and not for frequent cycling of the spray pump. Frequent spray pump cycling may lead to excessive scale buildup.

With electrical heater tape, heat trace and insulate all exposed water piping, including pump piping below the overflow level and make-up water lines.




Figure 26 – Nozzle Spray Pattern

**⚠ CAUTION**

Do not use the plastic drift eliminators as a walking, working, or storage surface. Stepping on or placing weight on an eliminator can result in physical injury and/or equipment damage. After ensuring that the fan and pump motors are locked and tagged out, lift and remove eliminators as necessary to perform recommended maintenance and inspections. If access to the top of the coil is required, place a piece of plywood at least 1/2 inch thick on top of the coil to protect the surface while performing the recommended maintenance. When finished, carefully remove the plywood and re-install any eliminators which were removed.

**NOTICE**

Do not use steam or high pressure water to clean PVC eliminators, fill or materials other than steel.

**Water Level Control**

There are two types of water level controls used on XLP3 Evaporative Condensers:

- Mechanical make-up valve assembly
- Optional electric water level control package

**Mechanical Make-up Valve Assembly**

A float-operated mechanical water make-up assembly is furnished as standard equipment on the unit. The standard make-up assembly consists of a corrosion resistant make-up valve connected to a float arm assembly actuated by a polystyrene-filled plastic float. The float is mounted on an all-thread rod held in

place by wing nuts. The cold water basin operating water level can be adjusted by repositioning the float and all-thread rod using the wing nuts provided.

- Inspect the make-up valve assembly monthly and adjust if necessary.
- Inspect the valve annually for leakage. Replace the valve seat if necessary.
- Maintain the make-up water supply pressure between 15 psig and 50 psig for proper operation. Frick recommends a pressure regulator valve (provided by others) for pressures over 50 psig.
- Set the initial basin water level by adjusting the wing nuts so that the make-up valve is completely closed when the water level in the cold water basin is at the operating level as stated in Table 4 on page 24.
- With the design thermal load and the average water pressure (15 to 50 psig) at the valve, the above setting will produce operating water levels as stated in Table 4 on page 24.
- If the thermal load is less than the design load at the time of unit start-up, the procedure may produce operating levels greater than those shown in Table 1. If operating levels are higher than specified, readjust the float in order to attain the recommended operating level.
- Closely monitor the water level in the cold water basin and adjust the level if necessary during the first 24 hours of operation.
- Operating at the recommended water level will ensure that the unit basin contains sufficient water volume to prevent air entrainment in the circulating pump during system start-up and provides sufficient excess basin capacity to accept the total system pull-down volume.

**NOTICE**

If the unit has been ordered with the optional electric water level control package or is intended for remote sump application, a mechanical water make-up valve will not be provided.

**Optional Electric Water Level Control Package**

As an option, an electric water level control package is available in lieu of the mechanical make-up assembly. The package consists of a probe-type liquid level control assembly and a slow-closing solenoid valve. Stainless steel electrodes, factory-set at predetermined lengths, extend from an electrode holder into the cold water basin.

- Clean the stainless steel electrodes periodically to prevent accumulations of scale, corrosion, sludge, or biological growth, which could interfere with the electrical circuit.
- The water level is maintained at the recommended operating level regardless of the system thermal load. Therefore, it is not recommended that the operating level be adjusted.
- During the start-up of units equipped with the electric water level control package, bypass the control unit in order to fill the unit to the overflow connection.

#### L.E.D. Status Codes

- **L.E.D. on steady:** Indicates normal operation.
- **Steady one second flashing:** Indicates dirty probes, reading in the capacitance mode. The unit will still operate but will give the following status code of 1 second on, 1 second off (steady 1 second flashing). This status code continue until the probes are cleaned and the power has been reset. Note: No other status codes will be displayed until the dirty probes are cleaned.
- **Two flashes and off for 5 seconds:** Indicates make-up valve ran for more than 1 hour. The unit will continue to fill, with the following status code of 1 second on, 1 second off, 1 second on and then off for 5 seconds before repeating. This status will continue until power has been reset. Possible causes: leaking tank, obstructed fill / defective valve or reduced flow rate.
- **Three flashes and off for 5 seconds:** Indicates shorted probes or highly conductive water. The unit will continue to operate but will give the following status code of 1 second on, 1 second off, 1 second on, 1 second off, 1 second on and then off for 5 seconds before repeating. This status will continue until the water is diluted or the short is removed from the probes and power is reset.
- **Four flashes and off for 5 seconds:** Indicates black probe (P6) reads covered, but white probe (P5) does not read covered (white should also be covered because it is longer than the black). This will cause the fill solenoid valve to short cycle and lead to premature failure of the fill valve. The unit will short cycle and give the status code of 1 second on, 1 second off, 1 second on, 1 second off, 1 second on, 1 second off, 1 second on and then off for 5 seconds before repeating. The unit will continue to short cycle until the condition has been corrected (clean white probe) and the power reset.
- **L.E.D. does not come on after power up or resetting power:** Indicates unit inoperative.

### CORROSION PROTECTION

Frick products are constructed of corrosion-resistant materials. Other materials listed below are used in the equipment construction:

- **Galvanized Steel Components:** Inspect the galvanized steel components for blemishes or corrosion. Wire brush and recoat the affected areas with a cold galvanizing compound such as zinc rich compound (ZRC).
- **Thermosetting Hybrid Polymer Components:** Galvanized steel components protected with the thermosetting hybrid polymer can be scratched, scraped, or blemished. To touch up these areas use a repair kit (Frick Part # 160133) available from your local Frick Representative.
- **Stainless Steel Components:** Inspect stainless steel components for signs of blemishes or corrosion. See "Long Term Care of Stainless Steel" on page 30 for cleaning and care instructions.
- **TripleGuard® Corrosion Protection System:** Inspect components protected with the TripleGuard® Corrosion Protection System for signs of deep scratches or blemishes, especially in areas with field penetrations. Touch these up with 3M™ Windo-Weld™ Super Fast Urethane which is

available through your local Frick Representative (Frick Part # RK1015).

## NOTICE

Since the quality of the ambient air and make-up water varies significantly from job site to job site, Frick strongly recommends obtaining the services of a qualified water treatment specialist prior to the initial start-up of the evaporative cooling equipment. Additionally, to protect against the risk of Legionella contamination, never operate the cooling equipment without adequate biological control.

### Water Treatment

A proper water treatment program, administered under the supervision of a competent water treatment specialist, is an essential part of routine maintenance to ensure the safe operation and longevity of evaporative cooling equipment, as well as other system components.

In evaporative cooling products, cooling is accomplished by evaporating a small portion of the recirculating water as it flows through the unit. As the water evaporates, the dissolved solids originally present in the water remain behind and if not controlled, the concentration of dissolved solids will increase rapidly. This can lead to corrosion, scale or biological fouling which may negatively affect heat transfer as well as the longevity of system components.

- **Corrosion** – Red rust on steel components and white rust on galvanized surfaces may affect the longevity of system components.
- **Scale Formation** – Scale, typically a calcium or magnesium based build-up, not only reduces heat transfer and system efficiency, but also may lead to under deposit corrosion. If scale is not controlled, it may continue building on critical components such as the fill and severely impact thermal performance.
- **Biological Fouling** – Slime and algae formations may reduce heat transfer, promote corrosion, and harbor pathogens such as Legionella.

### Corrosion and Scale Control

- To control corrosion and scale, maintain the water chemistry of the recirculating water within the parameters listed in Table 5. The specific measures required vary from system to system and are dependent on the chemistry of the make-up water, the metallurgy of the piping and heat transfer devices exposed to the recirculating water, and the temperatures at which the system will be operating.
- Bleed/blowdown, the continuous flow of a small portion of the recirculating water to a drain, is used to control the concentration of dissolved solids. On rare occasions, this may be adequate to control scale and corrosion. More often, chemical scale and corrosion inhibitors are necessary, which raise the allowable level of dissolved solids without the risk of scale and corrosion.
- Keep the chemically treated water within the guidelines given in Table 5. In cases where bleed/blowdown alone is being employed for corrosion and scale control without chemical treatment your water treatment specialist may recommend more conservative limits than those shown in Table 5.

**Gray Water and Reclaimed Water**

The use of water reclaimed from another process as a source of makeup water for evaporative cooling equipment can be considered as long as the resultant recirculating water chemistry conforms to the parameters noted in Table 5. It should be noted that using water reclaimed from other processes may increase the potential of corrosion, microbiological fouling, or scale formation. Gray water or reclaimed water should be avoided unless all the associated risks are understood and documented as part of the site specific treatment plan.

NOTICE
<ol style="list-style-type: none"> <li>1. Galvanized steel units require passivation in order to prevent white rust (refer to "Passivation").</li> <li>2. Hardness and alkalinity limits may be exceeded under certain circumstances. Consult your water treatment specialist for recommendations.</li> <li>3. The conversion factor used to determine conductivity is 0.625 (TDS = 0.625 x Conductivity).</li> <li>4. DuraTest™ Construction units have a TripleGuard® Corrosion Protection System basin.</li> <li>5. The guidelines above refer to the materials used in construction. Different combinations of materials may be used on the same unit.</li> <li>6. Water chemistry will change with operating temperatures. The recommended guidelines listed in Table 2 refers to water temperature at 95°F.</li> </ol>

**Chemical Treatment Requirements**

Chemical treatment programs must meet the following requirements:

- The chemicals must be compatible with the unit materials of construction as well as other materials used in the system (pipe, heat exchanger, etc.).
- Frick discourages acid dosing as means of scale control except for open circuit cooling towers with remote sump applications or towers constructed from stainless steel. This should be done at a point in the system where total mixing and dilution occur before reaching the evaporative

cooling equipment. The preferred injection point for chemical scale and corrosion inhibitors is on the discharge side of the system circulating pump(s). These chemicals should not be batch fed directly into the unit's cold water basin or water distribution system, as this can severely damage areas directly contacted.

- When chlorine is added to the system, free residual chlorine should not exceed 1 ppm, except as noted in start-up and shutdown section on Page 15. Exceeding this limit may accelerate corrosion.

**Passivation**

When new systems are first commissioned, special measures should be taken to ensure that galvanized steel surfaces are properly passivated to provide maximum protection from corrosion. Passivation is the formation of a protective, passive, oxide layer on galvanized steel surfaces. To ensure the galvanized steel surfaces are passivated, the pH of circulating water should be kept between 6.5 and 8.2 and calcium hardness between 50 and 600 ppm (as CaCO<sub>3</sub>) for four to eight weeks after start-up, or until new zinc surfaces turn dull gray in color. If white deposits form on galvanized steel surfaces after the pH is returned to normal service levels, it may be necessary to repeat the passivation process. In case the pH can't be kept below 8.2, a secondary approach is to conduct a chemical passivation using inorganic phosphate or film-forming passivation agents. Consult your water treatment specialist for specific recommendation.

NOTICE
<p><b>Stainless steel cold water basins and basins protected by the TripleGuard® Corrosion Protection System or thermosetting hybrid polymer do not require passivation. However, if the upper structure is galvanized steel, passivation is required on the galvanized area including any Hot Dip Galvanized After Fabrication (HDGAF) coil(s).</b></p>

**Biological Control**

- The warm, oxygen and nutrient rich environment inside evaporative cooling equipment provides an ideal environment conducive to the growth of algae, slime, and other micro-organisms. Uncontrolled, this can reduce heat

**Table 5 – Quality Guidelines for Treated Circulated Water**

Property of Water	Recommended Levels for Various Materials of Construction			
	Galvanized Steel	Thermosetting Hybrid Polymer	Type 304 Stainless Steel	TripleGuard® Corrosion Protection System or Type 316 Stainless Steel
pH	6.5 to 9.0[1]	6.5 to 9.2[1]	6.5 to 9.2[1]	6.5 to 9.5[1]
Total Suspended Solids	25 ppm	25 ppm	25 ppm	25 ppm
Total Dissolved Solids (TDS)	1,500 ppm	2,050 ppm	2,050 ppm	2,500 ppm
Conductivity	2,400 (micromhos/cm)	3,300 (micromhos/cm)	3,300 (micromhos/cm)	4,000 (micromhos/cm)
Alkalinity as CaCO <sub>3</sub>	500 ppm[2]	600 ppm[2]	600 ppm[2]	600 ppm[2]
Calcium Hardness as CaCO <sub>3</sub>	50 to 600 ppm[2]	50 to 750 ppm[2]	50 to 750 ppm[2]	50 to 750 ppm[2]
Chlorides (CL)	250 ppm	300 ppm	300 ppm	750 ppm
Sulfates	250 ppm	350 ppm	350 ppm	750 ppm
Silica	150 ppm	150 ppm	150 ppm	150 ppm

transfer, promote corrosion, and promote the growth of potentially harmful organisms such as Legionella.

- **To avoid biological contamination and minimize the risk of Legionella, initiate the biocide treatment program at start-up and continue on a regular basis thereafter in accordance with the treatment supplier's instructions.**
- Bleed/blowdown or chemical treatment used for corrosion and scale control alone is not adequate for control of biological contamination.
- Introduce solid or granular biocides through a chemical "pot" feeder installed in parallel with the system circulating pump. Diluted liquid biocides may be added directly to the cold water basin.

### Long Term Care of Stainless Steel

When the percentage of chromium in steel exceeds 10.5%, it is called stainless steel. The chromium in the steel reacts with the oxygen in the air to form a chromium-oxide surface layer, also called the passivation layer that provides the corrosion resistance in stainless steel.

#### Frick's Manufacturing Process

Frick takes precautions to prevent cross-contamination, processing galvanized and stainless steel parts separately. Also, stainless steel brushes are used to clean welds on stainless parts and care is taken to avoid scratching parts during processing. Organic cleaners are used to clean the finished product prior to shipping.

#### Jobsite Considerations

While stainless steel itself does not rust so long as the chromium-oxide surface layer is intact, it is not immune to contamination from its surroundings. Some common sources of surface contamination are:

- Dirt and soil
- Shop oil or grease that may carry other contaminants such as metal chips
- Machining or welding galvanized steel at the jobsite may cause debris to impinge itself into the stainless steel

These contaminants can deposit on the surface and scratch the passivation layer or prevent it from re-forming. They can also get trapped underneath the passivation layer and reduce corrosion resistance.

#### Recommended Cleaning Procedure

Stainless steel needs to be cleaned regularly to maintain the corrosion resistance as well as to maintain the overall aesthetics of the stainless steel.

It is fairly simple to clean most contaminants off the surface of stainless steel. Most dirt and soil can be cleaned with a clean cloth, warm water, and mild detergent. For persistent dirt, a little vinegar can be added in the cleaning water. It is important to always rinse the surface with warm water and wipe with a dry cloth after any cleaning, whether mild or aggressive.

- Fingerprints, mild stains or grease spots can be cleaned using organic solvents such as acetone, methyl or ethyl alcohol, or mineral spirits. Stainless steel wipes or glass cleaners commonly available in stores may also be used.

## NOTICE

**Never use chloride or chlorine based solvents such as bleach or muriatic (hydrochloric) acid to clean stainless steel. It is important to rinse the surface with warm water and wipe with a dry cloth after cleaning.**

- Occasionally the surface of stainless steel can get iron chips or shavings embedded in it from having galvanized steel machined or welded in the vicinity. The iron chips can start to rust, reducing the corrosion resistance of the stainless steel, and stain the surface giving the impression that the stainless steel is rusting. These types of contaminants require more aggressive cleaning. Mild abrasives such as Scotch-Brite™ products may be used where aesthetic considerations are not important followed by solvent cleaning with organic solvents as described above. It is important to rinse the surface with warm water and wipe with a dry cloth after cleaning.
- If the iron chips are not removed with the Scotch-Brite™ Products, electro-chemical cleaning may be required. Frick uses commercially available equipment for electrochemical cleaning in the field. Contact your local Frick Representative for more information.

## NOTICE

**Long term care of stainless steel information reprinted with permission from "The Care and Cleaning of Stainless Steel"; Specialty Steel Industry of North America; <http://www.ssina.com>.**

### System Cleaning

#### Coil Cleaning

The outside of the coil may require occasional cleaning. The chemicals used must be compatible with the materials being treated. For example, the standard coil outside is galvanized steel. The inside of the coil is black carbon steel. For specific recommendations on coil cleaning, contact a qualified consultant.

#### Weld Byproduct Cleaning

The installation and manufacturing processes commonly used for field assembly of steelpiped systems may leave weld byproducts inside coils and connecting piping (especially in refrigeration systems). It is common practice to install filters and/or strainers that remove contaminants during initial system operation. Shortly after system start-up, the filters and/or strainers should be cleaned or replaced.

### BLEED RATE

In evaporative cooling, evaporation of a small portion of the recirculating spray water as it flows through the equipment causes the cooling effect. As this water evaporates, the impurities originally present remain in the recirculating water. The concentration of the dissolved solids increases over time and can reach unacceptable levels. In addition, airborne impurities are often introduced into the recirculating water. If these impurities and contaminants are not effectively controlled, they can cause scaling, corrosion, and sludge accumulations that reduce heat transfer efficiency and increase system operating costs, potentially shortening

the useful life of the equipment. The degree to which dissolved solids and other impurities build up in the recirculating water may be defined as the cycles of concentration. Specifically, cycles of concentration equal the ratio of the concentration of dissolved solids (for example - chlorides, sulfates, etc.) in the recirculating water to the concentration of the same material in the make-up water.

- In order to optimize heat transfer efficiency and maximize equipment life, bleed or blowdown a small amount of recirculating water from the system. This controls the cycles of concentration to maintain the quality of the recirculating water within the guidelines given in Table 5, on page 25.
- Replenish the “bleed” water with fresh make-up water, thereby limiting the build-up of impurities.
- Bleed/blowdown:
  - To minimize water usage, accomplish the bleed automatically through a solenoid valve controlled by a conductivity meter. The set point is the water conductivity at the desired cycles of concentration and should be determined by a water treatment expert.

**Bleed Line Calculations:** Bleed rate is determined by the following formula:

$$B = \frac{E}{(n-1)}$$

- Where:
- B = Bleed Rate (USGPM)
  - E = Evaporation Rate (USGPM) = Q (USGPM) x R (°F) x 0.001
  - Q = Process Fluid Flow Rate (USGPM)
  - R = Range
  - n = Desired Number of Cycles of Concentration = CR/CM

The evaporation rate is dependent on the wet bulb temperature and load. The equation shown above provides the maximum bleed rate on the design day. Contact your local Frick representative for an exact calculation based on specific site conditions.

### NOTICE

**A proper water treatment program, administered under the supervision of a competent water treatment specialist, is an essential part of routine maintenance to ensure the safe operation and longevity of evaporative cooling equipment, as well as other system components.**

### NOTICE

**The solenoid valve and conductivity meter must be supplied by others. Evaporation is proportional to the load and will vary seasonally. Frick recommends the use of a conductivity meter to maximize water conservation.**

### NOTICE

- The approximate design evaporation rate (E) can be determined by any one of the following methods:**
- The evaporation rate is approximately 2 USGPM per 1 million BTUH of heat rejection.
  - The evaporation rate is approximately 3 USGPM per 100 tons of refrigeration.
  - **Evaporation Rate = Q (USGPM) \* R \* 0.001.**

**RECOMMENDED MAINTENANCE INTERVALS<sup>(1)</sup>**

<b>Inspect and clean as necessary:</b>	<b>Start-Up</b>	<b>Monthly</b>	<b>Quarterly</b>	<b>Annually</b>	<b>Shutdown</b>
Inspect general condition of the unit <sup>(2)</sup> and check unit for unusual noise or vibration	X	X			
Inspect cold water basin	X		X		
Flush water distribution system/Inspect spray nozzles	X		X		
Clean basin strainer	X	X			X
Drain basin and piping	X				X
Check and adjust water level in cold water basin	X	X			
Check operation of make-up valve	X	X			
Inspect coil			X		
Check and adjust bleed rate	X	X			
Inspect unit finish				X	
<b>Mechanical equipment system:</b>					
Check belt condition	X	X			
Adjust belt tension <sup>(3)</sup>	X		X		
Lubricate fan shaft bearings <sup>(4)</sup>	X		X		X
Lubricate motor base adjusting screw <sup>(4)</sup>	X		X		X
Check drive alignment <sup>(4)</sup>				X	
Check motor voltage and current	X		X		
Clean fan motor exterior	X		X		
Check fan motor for proper rotation	X				
Check general condition of the fan	X		X		
Check fan for uniform pitch <sup>(4)</sup>			X		
Check fan for rotation without obstruction	X		X		
Check and recoat steel shafts with RUST VETO <sup>®</sup> <sup>(4)</sup>	X		X		X
Check optional basin heater and stand alone Frick heater control panel				X	
Test optional vibration cutout switch <sup>(4)</sup>	X			X	

1. Recommended service intervals are the minimum for typical installations. Harsh environmental conditions may dictate more frequent servicing.
2. When operating in ambient temperatures below freezing, the unit should be inspected more frequently. Refer to "Cold Weather Operation" for more details.
3. Tension on new belts must be readjusted after the first 24 hours of operation and quarterly, thereafter.
4. On units equipped with Belt Drive Fan System only.

** DANGER**

**Rotating equipment will cause severe personal injury or death to persons who come in contact. Do not perform any service on or near the fans, motors, and drives, or inside the unit without first ensuring that the fans and pump motors are disconnected, locked out, and tagged out.**



**NOTES**

**Form 140.925-IOM (2019-04)**  
Supersedes: Nothing  
Subject to change without notice  
Published in USA · 04/19 · PDF

© 2019 Johnson Controls Int'l PLC - ALL RIGHTS RESERVED



**JOHNSON CONTROLS**  
100 Cumberland Valley Avenue  
Waynesboro, PA 17268-1206 USA  
Phone: 717-762-2121 · FAX: 717-762-8624  
[www.johnsoncontrols.com/frick](http://www.johnsoncontrols.com/frick)